



For 3" stone guard.

Bell Siphon hole making template instructions:

- 1) Print Templates.
- 2) Cut out each template.
- 3) Tape template to the bottom circumference of the PVC pipe.
- 4) Follow the template to drill holes around the bottom of the PVC pipe.

For 2" Bell cover.